


# COMMUNICATIONS SUPPLEMENT

**RS232-C & RS485/422 Data-Link  
50XM1000D/N Converter**

## MICROPROCESSOR-BASED SIGNAL CONVERTER



PN25060

**WARNING** notices as used in this manual apply to hazards or unsafe practices which could result in personal injury or death.

**CAUTION** notices apply to hazards or unsafe practices which could result in property damage.

**NOTES** highlight procedures and contain information which assist the operator in understanding the information contained in this manual.

All software, including design, appearance, algorithms and source codes, is owned and copyrighted by ABB Inc. or its suppliers.

#### WARNING

##### INSTRUCTION MANUALS

Do not install, maintain or operate this equipment without reading, understanding and following the proper ABB Inc. instructions and manuals, otherwise injury or damage may result.

##### POSSIBLE PROCESS UPSETS

Operation & maintenance must be performed only by qualified personnel and only after securing equipment controlled by this product. Adjusting or removing this product while it is in the system may upset the process being controlled. Some process upsets may cause injury or damage.

#### NOTICE

The information contained in this document is subject to change without notice. ABB Inc. reserves the right to make minor changes to this publication, such as company name & logos as well as other minor corrections, without necessarily changing the publication number.

ABB Inc., its affiliates, employees, and agents, and the authors of and contributors to this publication specifically disclaim all liabilities and warranties, express and implied (including warranties of merchantability and fitness for a particular purpose), for the accuracy, currency, completeness, and/or reliability of the information contained herein and/or for the fitness for any particular use and/or for the performance of any material and/or equipment selected in whole or part with the user of/or in reliance upon information contained herein. Selection of materials and/or equipment is at the sole risk of the user of this publication.

This document contains proprietary information of ABB Inc. and is issued in strict confidence. Its use, or reproduction for use, for the reverse engineering, development or manufacture of hardware or software described herein is prohibited. No part of this document may be photocopied or reproduced without the prior written consent of ABB Inc.

## Table of Contents

|                                                               |            |
|---------------------------------------------------------------|------------|
| <b>READ FIRST</b> .....                                       | <b>I</b>   |
| <b>1.0 Data Link Communications</b> .....                     | <b>1-1</b> |
| 1.1 General Discussion .....                                  | 1-1        |
| 1.1.1 Hardware Implementation .....                           | 1-2        |
| 1.1.1.1 RS232-C Interface (IEC type V24) .....                | 1-2        |
| 1.1.1.2 RS485 Interface .....                                 | 1-2        |
| 1.2 ASCII Communications Mode .....                           | 1-4        |
| 1.2.1 ASCII Communications Protocol .....                     | 1-4        |
| 1.2.2 Monitor Mode .....                                      | 1-5        |
| 1.2.2.1 Function Characters with Monitor Mode .....           | 1-6        |
| 1.2.2.2 AN: Display .....                                     | 1-7        |
| 1.2.2.3 DP: Damping .....                                     | 1-7        |
| 1.2.2.4 DI: Density .....                                     | 1-7        |
| 1.2.2.5 DF: Flow Rate in Engineering Units .....              | 1-8        |
| 1.2.2.6 DM: Multiplexed Display .....                         | 1-8        |
| 1.2.2.7 DL: Empty Pipe Detector .....                         | 1-8        |
| 1.2.2.8 DS: Threshold Empty Pipe Detector .....               | 1-8        |
| 1.2.2.9 ER: Error Register 0 .....                            | 1-9        |
| 1.2.2.10 E1: Error Register 1 .....                           | 1-10       |
| 1.2.2.11 EI: Engineering Units for Maximum Flow .....         | 1-10       |
| 1.2.2.12 EZ: Engineering Units for Totalizer .....            | 1-12       |
| 1.2.2.13 I> : Scaling Factors: Forward and Reverse Flow ..... | 1-12       |
| 1.2.2.14 I< : Scaling Factor Reverse Flow .....               | 1-13       |
| 1.2.2.15 IO: Current Signal Output .....                      | 1-13       |
| 1.2.2.16 IA: Alarm Current Signal Output .....                | 1-13       |
| 1.2.2.17 M: Percentage Flow Rate .....                        | 1-13       |
| 1.2.2.18 NG: System Zero Reference .....                      | 1-14       |
| 1.2.2.19 NW: Meter Size .....                                 | 1-15       |
| 1.2.2.20 PR: Firmware Version .....                           | 1-16       |
| 1.2.2.21 Q>: Maximum Flow Rate (Range) .....                  | 1-16       |
| 1.2.2.22 Q<: Maximum Reverse Flow Rate .....                  | 1-16       |
| 1.2.2.23 QN: Maximum Flow Rate of Meter Size .....            | 1-16       |
| 1.2.2.24 ST: Status Register .....                            | 1-17       |
| 1.2.2.25 SU: Noise Suppression .....                          | 1-17       |
| 1.2.2.26 SM: Low Flow Cut-Off .....                           | 1-18       |
| 1.2.2.27 SP: Language .....                                   | 1-18       |
| 1.2.2.28 Z>: Totalizer Forward Flow .....                     | 1-18       |
| 1.2.2.29 Z<: Totalizer Reverse Flow .....                     | 1-19       |
| 1.2.3 Configuration Mode .....                                | 1-19       |
| 1.2.3.1 Configuration Mode Functions .....                    | 1-20       |
| 1.2.3.2 AD: Address .....                                     | 1-20       |
| 1.2.3.3 AN: Display .....                                     | 1-21       |
| 1.2.3.4 BA: Baud Rate .....                                   | 1-21       |
| 1.2.3.5 DP: Damping .....                                     | 1-22       |
| 1.2.3.6 DI: Density .....                                     | 1-22       |
| 1.2.3.7 DM: Multiplexed Display .....                         | 1-23       |
| 1.2.3.8 DR: Empty Pipe Detector .....                         | 1-23       |
| 1.2.3.9 DS: Empty Pipe Detector Threshold .....               | 1-23       |
| 1.2.3.10 EI: Engineering Units for Maximum Flow .....         | 1-24       |

|                                                         |      |
|---------------------------------------------------------|------|
| 1.2.3.11 EZ: Engineering Units for Totalizer . . . . .  | 1-24 |
| 1.2.3.12 I> and I<: Pulse Scaling Factor . . . . .      | 1-24 |
| 1.2.3.13 IO: Current Signal Output . . . . .            | 1-25 |
| 1.2.3.14 IA: Alarm Current Signal Output . . . . .      | 1-25 |
| 1.2.3.15 LZ: Totalizer Reset. . . . .                   | 1-26 |
| 1.2.3.16 LV: Forward Flow Totalizer Reset . . . . .     | 1-26 |
| 1.2.3.17 LR: Reverse Flow Totalizer Reset . . . . .     | 1-26 |
| 1.2.3.18 NW: Meter Size . . . . .                       | 1-26 |
| 1.2.3.19 NG: System Zero Reference . . . . .            | 1-26 |
| 1.2.3.20 Q> and Q<: Maximum Flow Rate (Range) . . . . . | 1-27 |
| 1.2.3.21 QN: Maximum Flow Rate of Meter Size . . . . .  | 1-27 |
| 1.2.3.22 SM: Low Flow Cut-Off . . . . .                 | 1-27 |
| 1.2.3.23 SP: Language . . . . .                         | 1-28 |
| 1.2.3.24 SU: Noise Suppression . . . . .                | 1-28 |
| 1.3 Error Messages . . . . .                            | 1-29 |
| 1.3.2 Configuration Error Messages . . . . .            | 1-30 |
| 1.4 Remote Display . . . . .                            | 1-31 |
| 1.4.1 ANSI Terminal . . . . .                           | 1-31 |
| 1.4.2 Data Terminal. . . . .                            | 1-33 |

### **Table List**

---

|                                              |      |
|----------------------------------------------|------|
| TABLE 1-1. FUNCTION CODES . . . . .          | 1-6  |
| TABLE 1-3. TOTALIZATION UNIT INDEX . . . . . | 1-12 |
| TABLE 1-4. INDEX OF METER SIZES . . . . .    | 1-15 |
| TABLE 1-5. LANGUAGE INDEX . . . . .          | 1-18 |
| TABLE 1-6. BAUD RATE INDEX . . . . .         | 1-21 |
| TABLE 1-7. ANSI TERMINAL KEYS . . . . .      | 1-32 |

### **Figure List**

---

|                                                             |     |
|-------------------------------------------------------------|-----|
| FIGURE 1-1. BAUD RATE VS. CABLE LENGTH FOR RS 232 . . . . . | 1-3 |
|-------------------------------------------------------------|-----|

## **READ FIRST**

---

**WARNING**

**INSTRUCTION MANUALS**

Do not install, maintain, or operate this equipment without reading, understanding and following the proper factory-supplied instructions and manuals, otherwise injury or damage may result.

**RETURN OF EQUIPMENT**

All Flowmeters and/or Signal Converters being returned to the factory for repair must be free of any hazardous materials (acids, alkalis, solvents, etc). A Material Safety Data Sheet (MSDS) for all process liquids must accompany returned equipment. Contact the factory for authorization prior to returning equipment.

Read these instructions before starting installation;  
save these instructions for future reference.

### **Contacting the Factory. . .**

Should assistance be required with any of the company's products, contact the following:

**Telephone:**

**Automation Services Call Center  
1-800-HELP-365**

**E-Mail:**

**[ins.techsupport@us.abb.com](mailto:ins.techsupport@us.abb.com)**

# 1.0 Data Link Communications

---

## 1.1 General Discussion

---

A digital data link, either RS232-C or RS485/422, can be supplied as an optional feature in the 50XM1000 Signal Converter (see 50XM1000 Instruction Manual Model Number Breakdown, Output Options in Section 1.2). Each of the above options requires the addition of a different hardware module to the converter. The choice of RS232-C communications provides a serial data link between two instruments, e.g., a video display terminal such as a VT100 (or host computer ) and the signal converter. RS485 is useful for multi-instrument bus communications and is capable of being expanded to establish a link with up to 32 nodes.

It is common practice to have intelligent instruments (micro-computers) communicate through a network to a centralized control point. This permits plantwide monitoring and supervisory applications by a single operator. The host device uses ASCII PROTOCOL.

When the signal converter is placed in the ASCII communications mode an ASCII terminal, or a computer with the appropriate firmware to emulate an ASCII terminal, can be connected to the data link port. The terminal can then be used to monitor or modify the data base parameters of the converter or other intelligent instruments connected to the data link.

The RS232C interface permits one to one communication between two devices separated by no more than 50 feet (15 m) at baud rates not exceeding 9600 (refer to Figure 1-1).

The RS422A/RS485 interface is a high speed link used by many intelligent instruments. The newer RS485 version, used in the 50XM, permits any transmitter to be shut off or "tri-stated" when not in use. For the company's instruments, this means that up to 32 instruments may "talk" over one data link. This link can send data at 28.8 k baud over lines up to 4000 feet (1200 m).

It is also possible to communicate with the PC through use of a modem and telephone line. A SCADA Adaptor is required for modem applications. In this arrangement, the number of instruments that may be examined is practically limitless. It should be noted that hardware adapters are available to convert from one type of hardware link to another. In particular, to use a PC with multiple instruments, it might be necessary to purchase one RS232 to RS422/485 converter for use at the PC.

### 1.1.1 Hardware Implementation

The signal converter may be equipped with one of two different modular PC assemblies for communications, which are:

- a) RS232-C (IEC type V24)
- b) RS485/422

The RS232-C interface is commonly used in a serial loop (one-to-one). Communications interface RS485 has the capability to serve a larger number of bus-linked users in a multi-drop application.

#### 1.1.1.1 RS232-C Interface (IEC type V24)

##### RS232-C Engineering Specifications

|                                      |                |
|--------------------------------------|----------------|
| Electrical transmission mode:        | common mode    |
| Number of transmitters:              | 1              |
| Number of receivers:                 | 1              |
| Cable length maximum:                | 50 feet (15 m) |
| Communications rate, maximum:        | 20 kBaud*      |
| Signal voltage, no load:             | ±15 volts      |
| Signal voltage under load condition: | ±5 volts       |

##### RS232-C Installation

|                  |               |
|------------------|---------------|
| I/O TERMINAL ID: |               |
| TXD              | Transmit Data |
| RXD              | Receive Data  |
| -                | Ground        |

\* limited to 9600 baud with 50 feet (15 m) of cable (see Figure 1-1 )

#### 1.1.1.2 RS485 Interface

##### RS485 Engineering Specifications


|                                      |                                                |
|--------------------------------------|------------------------------------------------|
| Electrical transmission mode:        | balanced mode                                  |
| Number of transmitters:              | 32                                             |
| Number of receivers:                 | 32                                             |
| Cable length maximum:                | 4000 feet (1200 m)<br>(see the following note) |
| Communications rate, maximum:        | 10 MBaud                                       |
| Signal voltage, no load:             | 5 Volts                                        |
| Signal voltage under load condition: | 1.5 Volts                                      |

RS485 Installation

I/O TERMINAL ID:

- T+ Transmit Data +
- T- Transmit Data -
- R+ Receive Data +
- R- Receive Data -

**NOTE**  
Refer to applicable system interconnection diagram for signal wiring. Cable length is a function of transmission speed.



**FIGURE 1-1. BAUD RATE VS. CABLE LENGTH FOR RS 232**



## 1.2 ASCII Communications Mode

### 1.2.1 ASCII Communications Protocol

Communications is always started from the host computer. The signal converter responds only to host inquiries. Any terminal device such as a VT100 or a PC with serial port may be used in this mode but a message must be typed each time a new parameter is desired. Signal converter data may be requested by the host in monitor mode, while data modification by the host is reserved for configuration mode.

Communication via the data link always starts with a 'Start of Header' character (SOH = 01H = <CTRL> A), followed by a 'M' for monitor mode or 'P' for configuration (programming) mode, followed by the two digit instrument address. The address is succeeded by two characters for the requested function, and optionally a maximum of eight data bytes. Carriage return (CR) and line feed (LF) characters are the terminators for a message transfer. A byte is defined as 7 data bits and one stop bit (even parity). An example of signal format is provided in Sub-Section 1.2.2.

The signal converter response also starts with a SOH character, followed by the function characters and optionally up to eight data bytes. Completion of the message is indicated by the CR and LF characters. Message data may be furnished with a minus sign (-) and a decimal point (.) for fractional decimals. Leading or complimentary zeros need not be sent with the message.

All received data is checked by the signal converter in various ways. In addition to checking each transmitted byte for even parity, the converter monitors a message for exact conformance with the protocol conventions (function characters as well as number and type of data). Before the new data is activated, it is examined for validity. In case of nonconformity, an error message is sent back to the host (function character 'X' followed by a two digit error code number). If the data passes the check, it is activated by the 50XM1000 and an acknowledge message of the exact same format as the received message is returned to the host computer. This completes one data exchange.

### 1.2.2 Monitor Mode

This mode of operation enables the interrogation of all variable parameters as well as status information.

The complimenting protocols are as follows:

a) Host interrogation

Host Computer to signal converter:

| SOH | M | A1 | A0 | K1 | K0 | CR | LF |                                    |
|-----|---|----|----|----|----|----|----|------------------------------------|
| .   | . | .  | .  | .  | .  | .  | .  | .                                  |
| .   | . | .  | .  | .  | .  | .  | .  | .                                  |
| .   | . | .  | .  | .  | .  | .  | .  | Line Feed = 0AH                    |
| .   | . | .  | .  | .  | .  | .  | .  | Carriage Return = 0DH              |
| .   | . | .  | .  | .  | .  | .  | .  | two ASCII Function Characters      |
| .   | . | .  | .  | .  | .  | .  | .  | two digit Address in ASCII format. |
| .   | . | .  | .  | .  | .  | .  | .  | Monitor Mode                       |
| .   | . | .  | .  | .  | .  | .  | .  | Start of Header = 01H              |

**NOTE**

When using a personal computer, the following control characters on the keyboard are used, either individually or in combination, to generate various message characters.

| <u>Definition</u> | <u>Message Character</u> | <u>IBM Keyboard</u> | <u>Hex</u> |
|-------------------|--------------------------|---------------------|------------|
| Start of Header   | SOH                      | <CTRL> A            | 01         |
| Carriage Return   | CR                       | ENTER               | 0D         |
| Line Feed         | LF                       | *SHIFT+ENTER        | 0A         |
| Escape            | ESC                      | *F2                 | 1B         |

\*Applicable only for terminal emulator program EM220. These characters may be generated by other key(s) when using a different emulation program.

b) Response from signal converter  
signal converter to host computer:

```

SOH K1 K0 D7 - D0 CR LF
. . . . .
. . . . .
. . . . . Line Feed = 0AH
. . . . . Carriage Return = 0DH
. . . . . maximum 8 ASCII data bytes
. . . . . two ASCII Function Characters
Start of Header = 01H
    
```

A maximum of eight data bytes including decimal point (.) and minus sign (-) can be sent by the signal converter. The instrument address must always be entered with two digits (00 - 31).

### 1.2.2.1 Function Characters with Monitor Mode

Function characters are the means of addressing the signal converter operating parameters and status data. Only capital letters are accepted as proper entry. A list of function codes that can be used in monitor mode are given in Table 1-1.

**TABLE 1-1. FUNCTION CODES**

|                                   |    |
|-----------------------------------|----|
| Display                           | AN |
| Damping                           | DP |
| Density                           | DI |
| Flow Rate in Engr Units           | DF |
| Multiplexed Display               | DM |
| Empty Pipe Detector               | DL |
| Threshold (Empty Pipe Detector)   | DS |
| Error Register 0                  | ER |
| Error Register 1                  | E1 |
| Engr Units for Maximum Flow       | EI |
| Engr Units for Totalizer          | EZ |
| Scaling Factor-Forward Flow       | I> |
| Scaling Factor-Reverse Flow       | I< |
| Current Signal Output             | IO |
| Alarm Current Signal Output       | IA |
| Percentage Flow Rate              | M  |
| System Zero Reference             | NG |
| Meter Size                        | NW |
| Firmware Version                  | PR |
| Maximum Forward Flow Rate (range) | Q> |
| Maximum Reverse Flow Rate         | Q< |
| Maximum Flow Rate of Meter Size   | QN |
| Status Register                   | ST |
| Noise Suppression                 | SU |
| Low Flow Cut-off                  | SM |
| Language                          | SP |
| Totalizer Forward Flow            | Z> |
| Totalizer Reverse Flow            | Z< |

### 1.2.2.2 AN: Display

The converter flow rate display units can be in percent or engineering units (e.g. l/min). Data presentation is one digit.

| <u>Index No.</u> | <u>Meaning</u>            |
|------------------|---------------------------|
| 0                | Percent display           |
| 1                | Engineering units display |

Example:

Flow converter with address 00 displays the flow rate in percent.

|           |                    |
|-----------|--------------------|
| Host      | SOH M 0 0 AN CR LF |
| Converter | SOH AN 0 CR LF     |

### 1.2.2.3 DP: Damping

The damping parameter is presented in seconds, seven data bytes.

Example:

Instrument number 12 is configured for 12.5 seconds damping.

|           |                             |          |
|-----------|-----------------------------|----------|
| Host      | SOH M 1 2 D P CR LF         | damping? |
| Converter | SOH D P 1 2 . 5 0 0 0 CR LF | 12.5 s.  |

### 1.2.2.4 DI: Density

The density parameter is presented in g/cm<sup>3</sup>, seven data bytes.

Example:

Instrument number 03 is configured for 0.8 g/ccm density.

|           |                             |            |
|-----------|-----------------------------|------------|
| Host      | SOH M 0 3 D I CR LF         | density?   |
| Converter | SOH D I 0 . 8 0 0 0 0 CR LF | 0.8 g/ccm. |

### 1.2.2.5 DF: Flow Rate in Engineering Units

The converter flow rate display is interrogated. Engineering units are as specified under the EI function (1.2.2.11). Data presentation is seven digits.

Example:

The flow rate of converter 00 shall be requested.

|           |                             |                    |
|-----------|-----------------------------|--------------------|
| Host      | SOH M 0 0 E I CR LF         | engineering units? |
| Converter | SOH E I 0 0 1 CR LF         | L/minute           |
| Host      | SOH M 0 0 D F CR LF         | flow rate?         |
| Converter | SOH D F 1 5 . 6 7 0 1 CR LF | 15.6701 L/minute   |

### 1.2.2.6 DM: Multiplexed Display

Interrogation of the display mode. The presentation is single digit.

| <u>Index Number</u> | <u>Meaning</u>             |
|---------------------|----------------------------|
| 0                   | Multiplex display mode off |
| 1                   | Multiplex display mode on  |

### 1.2.2.7 DL: Empty Pipe Detector

Interrogation of the empty pipe detector function state (if available). The presentation is single digit.

| <u>Index Number</u> | <u>Meaning</u>          |
|---------------------|-------------------------|
| 0                   | Empty pipe detector off |
| 1                   | Empty pipe detector on  |

### 1.2.2.8 DS: Threshold Empty Pipe Detector

Interrogation of the current empty pipe detector threshold setting. The presentation is always three digits.

Example:

Instrument at address 12 is requested to report if its empty pipe detector is activated and what the threshold level is.

|           |                     |                  |
|-----------|---------------------|------------------|
| Host      | SOH M 1 2 D L CR LF | detector status? |
| Converter | SOH D L 1 CR LF     | on.              |
| Host      | SOH M 1 2 D S CR LF | threshold level? |
| Converter | SOH D S 0 7 5 CR LF | 75.              |

1.2.2.9 ER: Error Register 0

NOTE  
Do not confuse data presented in the Error Registers with the error codes described in section 1.3.1 and 1.3.2.

This data register provides information about the processor recorded errors. The eight register bits represent eight different error types which are displayed as ASCII characters with the following format:

| Bit7 | Bit6 | Bit5 | Bit4 | Bit3 | Bit2 | Bit1 | Bit0                                |
|------|------|------|------|------|------|------|-------------------------------------|
| .    | .    | .    | .    | .    | .    | .    | .                                   |
| .    | .    | .    | .    | .    | .    | .    | .                                   |
| .    | .    | .    | .    | .    | .    | .    | ERROR 1                             |
| .    | .    | .    | .    | .    | .    | .    | A/D converter                       |
| .    | .    | .    | .    | .    | .    | .    | positive out of range               |
| .    | .    | .    | .    | .    | .    | .    | ERROR 2                             |
| .    | .    | .    | .    | .    | .    | .    | Vref too low                        |
| .    | .    | .    | .    | .    | .    | .    | ERROR 3                             |
| .    | .    | .    | .    | .    | .    | .    | flow rate exceeding 130%            |
| .    | .    | .    | .    | .    | .    | .    | ERROR 4                             |
| .    | .    | .    | .    | .    | .    | .    | external cut off                    |
| .    | .    | .    | .    | .    | .    | .    | ERROR 5                             |
| .    | .    | .    | .    | .    | .    | .    | NVRAM data corrupted                |
| .    | .    | .    | .    | .    | .    | .    | ERROR 1.                            |
| .    | .    | .    | .    | .    | .    | .    | A/D converter negative out of range |
| .    | .    | .    | .    | .    | .    | .    | ERROR 7                             |
| .    | .    | .    | .    | .    | .    | .    | Vref too high (negative)            |
| .    | .    | .    | .    | .    | .    | .    | ERROR 8                             |
| .    | .    | .    | .    | .    | .    | .    | Vref too high (positive)            |

Error messages are valid if the appropriate bits are set in the error register and if bit 7(=1) of the status register is set simultaneously (ST - 1.2.2.24). Data presentation is always eight digits long.

Example:

Instrument 05 is interrogated.

|           |                               |          |
|-----------|-------------------------------|----------|
| Host      | SOH M 0 5 E R CR LF           | error?   |
| Converter | SOH E R 0 0 0 0 0 1 0 0 CR LF | error 3. |

Converter 05 reports an error: flow rate > 130 %.

### 1.2.2.10 E1: Error Register 1

See Error Register 0 (1.2.2.9 ER).

Bit7 Bit6 Bit5 Bit4 Bit3 Bit2 Bit1 Bit0

.  
.  
ERROR 0  
empty pipe

(Bit 1 through bit 7 have no meaning.)

### 1.2.2.11 E1: Engineering Units for Maximum Flow

Units for Qmax DN (QN - 1.2.2.23), Qmax forward and reverse flow rate (Q> - 1.2.2.21), Qmax reverse flow rate (Q< - 1.2.2.22), and current flow rate in engineering units (DF - 1.2.2.5).

Data representation is always three digits.

Index numbers 224, 225 and 226 (US thousand gallons) are configurable (see Table 1-2). Default is in US thousand gallons (refer to 3.3.12).

**TABLE 1-2. ENGINEERING FLOW UNIT INDEX**

| <b>Index Number</b> | <b>Symbol</b>       | <b>Definition</b>                  |
|---------------------|---------------------|------------------------------------|
| 000                 | l/s                 | Liters                             |
| 001                 | l/min               |                                    |
| 002                 | l/h                 |                                    |
| 016                 | hl/s                | Hectoliters                        |
| 017                 | hl/min              |                                    |
| 018                 | hl/h                |                                    |
| 032                 | m <sup>3</sup> /s   | Cubic Meters                       |
| 033                 | m <sup>3</sup> /min |                                    |
| 034                 | m <sup>3</sup> /h   |                                    |
| 048                 | igps                | Imperial Gallons                   |
| 049                 | igpm                |                                    |
| 050                 | igph                |                                    |
| 064                 | mgd                 | US Gallons                         |
| 065                 | gpm                 |                                    |
| 066                 | gph                 |                                    |
| 080                 | bbl/s               | Barrels (31 gal)                   |
| 081                 | bbl/min             |                                    |
| 082                 | bbl/h               |                                    |
| 096                 | bls/day             | Barrels (42 gal)                   |
| 097                 | bls/min             |                                    |
| 098                 | bls/h               |                                    |
| 112                 | kg/s                | Kilograms                          |
| 113                 | kg/min              |                                    |
| 114                 | kg/h                |                                    |
| 128                 | t/s                 | Metric Tons                        |
| 129                 | t/min               |                                    |
| 130                 | t/h                 |                                    |
| 144                 | gram/s              | Grams                              |
| 145                 | gram/min            |                                    |
| 146                 | gram/h              |                                    |
| 160                 | ml/s                | Milliliters                        |
| 161                 | ml/min              |                                    |
| 162                 | ml/h                |                                    |
| 176                 | Ml/min              | Megaliters (million liters)        |
| 177                 | Ml/h                |                                    |
| 178                 | Ml/day              |                                    |
| 192                 | lbs/s               | Pounds                             |
| 193                 | lbs/min             |                                    |
| 194                 | lbs/h               |                                    |
| 208                 | uton/min            | US Tons                            |
| 209                 | uton/h              |                                    |
| 210                 | uton/day            |                                    |
| 224                 | kgal/s              | US thousand gallons (configurable) |
| 225                 | kgal/min            |                                    |
| 226                 | kgal/h              |                                    |



**1.2.2.12 EZ: Engineering Units for Totalizer**

This parameter defines the engineering units for the flow totalizers (Z> - 1.2.2.28), reverse flow totalizer (Z< - 1.2.2.29), flow scaling factor (I> - 1.2.2.13).

Data representation is always three digits.

**TABLE 1-3. TOTALIZATION UNIT INDEX**

| <b>Index Number</b> | <b>Symbol</b>  | <b>Definition</b>   |
|---------------------|----------------|---------------------|
| 000                 | l              | Liters              |
| 001                 | hl             | Hectoliters         |
| 002                 | m <sup>3</sup> | Cubic Meters        |
| 003                 | igal           | Imperial Gallons    |
| 004                 | ugal           | US Gallons          |
| 005                 | umg            | Million US Gallons  |
| 006                 | bbl            | Barrels (31 gal)    |
| 007                 | bls            | Barrels (42 gal)    |
| 008                 | kg             | Kilograms           |
| 009                 | t              | Metric Tons         |
| 010                 | g              | Grams               |
| 011                 | ml             | Milliliters         |
| 012                 | MI             | Megaliters          |
| 013                 | lbs            | Pounds              |
| 014                 | uton           | US Tons             |
| *015                | kgal           | US thousand gallons |

\* configurable

Example:

The Totalizer value of flow converter 07 is to be requested.

|           |                             |                         |
|-----------|-----------------------------|-------------------------|
| Host      | SOH M 0 7 E Z CR LF         | totalizer engrg. units? |
| Converter | SOH E Z 0 0 2 CR LF         | m <sup>3</sup>          |
| Host      | SOH M 0 7 Z > CR LF         | forward flow totalizer? |
| Converter | SOH Z > 1 2 4 . 5 0 0 CR LF | 124.5 m <sup>3</sup>    |

**1.2.2.13 I> : Scaling Factors: Forward and Reverse Flow**

Output of the pulse scaling factor for forward flow (pulses/unit). Engineering units are stored with the Totalizer (EZ) parameter (see 1.2.2.12). Data presentation is seven data bytes.

Example:

The pulse scaling factor for forward flow of Signal Converter 07 is to be requested.

|           |                             |                                    |
|-----------|-----------------------------|------------------------------------|
| Host      | SOH M 0 7 E Z CR LF         | totalizer engrg. units?            |
| Converter | SOH E Z 0 0 2 CR LF         | m <sup>3</sup>                     |
| Host      | SOH M 0 7 I > CR LF         | pulse scaling factor-forward flow? |
| Converter | SOH I > 1 0 . 0 0 0 0 CR LF | 10 pulses/m <sup>3</sup>           |

**1.2.2.14 I< : Scaling Factor Reverse Flow**

See Scaling Factor Forward Flow (1.2.2.13).

**1.2.2.15 IO: Current Signal Output**

The presently configured current output signal is coded into a three digit parameter.

| <u>Index Number</u> | <u>Meaning</u> |
|---------------------|----------------|
| 000                 | 0-20 mA        |
| 001                 | 4-20 mA        |
| 002                 | 0-10 mA        |
| 003                 | 2-10 mA        |
| 004                 | 0-10-20        |
| 005                 | 4-12-20        |

**1.2.2.16 IA: Alarm Current Signal Output**

In case of an alarm status both the current and frequency outputs will go to the predetermined value. Data presentation is a single digit.

| <u>Index Number</u> | <u>Meaning</u> |
|---------------------|----------------|
| 0                   | 0%             |
| 1                   | 130%           |

### **1.2.2.17 M: Percentage Flow Rate**

In this case only one function character needs to be sent, a second one will be ignored.

Depending on the flow direction the converter will respond either with a '>' for forward flow or with a '<' character for reverse flow as the second function character. Data presentation is six digits .

Example:

The flow rate of converter 08 is interrogated.

|           |                           |                  |
|-----------|---------------------------|------------------|
| Host      | SOH M 0 8 M CR LF         | flow rate?       |
| Converter | SOH M < 9 0 . 0 1 5 CR LF | 90.015% reverse. |

### **1.2.2.18 NG: System Zero Reference**

Report the configured system zero reference in Hz. Data presentation is six digits.

Example:

Instrument 07 is requested to send its system zero reference data.

|           |                           |                 |
|-----------|---------------------------|-----------------|
| Host      | SOH M 0 7 N G CR LF       | zero reference? |
| Converter | SOH N G 1 . 5 6 3 3 CR LF | 1.5633 Hz       |

**1.2.2.19 NW: Meter Size (The meter size is reported as a three digit index number.)**

**TABLE 1-4. INDEX OF METER SIZES**

| Index Number | Meter Sizes |     |
|--------------|-------------|-----|
|              | inches      | mm  |
| 000          | 1/10        | 3   |
| 001          | 5/32        | 4   |
| 002          | 3/16        | 5   |
| 003          | 1/4         | 6   |
| 004          | 5/16        | 8   |
| 005          | 3/8         | 10  |
| 006          | 1/2         | 15  |
| 007          | 3/4         | 20  |
| 008          | 1           | 25  |
| 009          | 1 1/4       | 32  |
| 010          | 1 1/2       | 40  |
| 011          | 2           | 50  |
| 012          | 2 1/2       | 65  |
| 013          | 3           | 80  |
| 014          | 4           | 100 |
| 015          | 5           | 125 |
| 016          | 6           | 150 |
| 017          | 8           | 200 |
| 018          | 10          | 250 |
| 019          | 12          | 300 |
| 020          | 14          | 350 |
| 021          | 16          | 400 |
| 022          | 18          | 450 |

| Index Number | Meter Sizes |      |
|--------------|-------------|------|
|              | inches      | mm   |
| 023          | 20          | 500  |
| 024          | 24          | 600  |
| 025          | 28          | 700  |
| 026          | 30          | 750  |
| 027          | 32          | 800  |
| 028          | 36          | 900  |
| 029          | 40          | 1000 |
| 030          | 42          | 1100 |
| 031          | 48          | 1200 |
| 032          | 51          | 1300 |
| 033          | 54          | 1400 |
| 034          | 60          | 1500 |
| 035          | 64          | 1600 |
| 036          | 66          | 1700 |
| 037          | 72          | 1800 |
| 038          | 78          | 2000 |
| 043          | 1/25        | 1    |
| 045          | 1/12        | 2    |
| 44           | 1/17        | 1.5  |
| 39           | 82          | 2100 |
| 40           | 86          | 2200 |
| 41           | 90          | 2300 |
| 42           | 94          | 2400 |

Example:

The converter at address 25 is requested to report the meter size.

|           |                     |                  |
|-----------|---------------------|------------------|
| Host      | SOH M 2 5 N W CR LF | meter size?      |
| Converter | SOH N W 0 2 3 CR LF | 20 inch (500 mm) |

### 1.2.2.20 PR: Firmware Version

Reporting of the firmware version number. The data length is eight alphanumeric.

Example:

What is the firmware version number of Instrument 09?

|           |                         |                       |
|-----------|-------------------------|-----------------------|
| Host      | SOH M 0 9 P R CR LF     | firmware version?     |
| Converter | SOH P R B 123 A11 CR LF | Rev. D.10 implemented |

### 1.2.2.21 Q>: Maximum Flow Rate (Range)

Reporting of the setting of Qmax forward flow rate. Engineering units are stored with parameter EI, section 1.2.2.11. The presentation is seven data bytes.

### 1.2.2.22 Q<: Maximum Reverse Flow Rate

Reverse flow rate is automatically set to the same value as the forward flow rate (see 1.2.2.21).

### 1.2.2.23 QN: Maximum Flow Rate of Meter Size

Qmax of set meter size at a flow velocity of 10 m/s. Engineering units are stored with parameter EI, section 1.2.2.11. The presentation is seven data bytes.

Example:

Converter 07 is requested to report Qmax DN, Qmax forward flow and Qmax reverse flow. The engineering units are to be reported first.

|           |                             |                    |
|-----------|-----------------------------|--------------------|
| Host      | SOH M 0 7 E I CR LF         | engineering units? |
| Converter | SOH E I 0 0 1 CR LF         | l/min              |
| Host      | SOH M 0 7 Q N CR LF         | Qmax DN?           |
| Converter | SOH Q N 1 5 0 . 0 0 0 CR LF | 150.0 l/min        |
| Host      | SOH M 0 7 Q > CR LF         | Qmax forward?      |
| Converter | SOH Q > 7 5 . 0 0 0 0 CR LF | 75.0 l/min         |
| Host      | SOH M 0 7 Q < CR LF         | Qmax reverse?      |
| Converter | SOH Q < 7 . 0 0 0 0 0 CR LF | 7.0 l/min          |

### 1.2.2.24 ST: Status Register

The status register bits are represented as ASCII characters '0' or '1' in the following order:

|      |      |      |      |      |      |      |      |                                       |
|------|------|------|------|------|------|------|------|---------------------------------------|
| Bit7 | Bit6 | Bit5 | Bit4 | Bit3 | Bit2 | Bit1 | Bit0 |                                       |
| .    | .    | .    | .    | .    | .    | .    | .    |                                       |
| .    | .    | .    | .    | .    | .    | .    | .    |                                       |
| .    | .    | .    | .    | .    | .    | .    | .    | forward flow totalizer                |
| .    | .    | .    | .    | .    | .    | .    | .    | overflow                              |
| .    | .    | .    | .    | .    | .    | .    | .    | reverse flow totalizer                |
| .    | .    | .    | .    | .    | .    | .    | .    | overflow                              |
| .    | .    | .    | .    | .    | .    | .    | .    | internally used                       |
| .    | .    | .    | .    | .    | .    | .    | .    | parameter change via keypad           |
| .    | .    | .    | .    | .    | .    | .    | .    | (automatically reset when being used) |
| .    | .    | .    | .    | .    | .    | .    | .    | internally used                       |
| .    | .    | .    | .    | .    | .    | .    | .    | low flow cut-off enabled              |
| .    | .    | .    | .    | .    | .    | .    | .    | internally used                       |

error register messages are valid

Data is presented as eight characters. For example, the "status" response from the instrument at address 09 could be:

|           |                             |                                              |
|-----------|-----------------------------|----------------------------------------------|
| Host      | SOH M 0 9 S T CR LF         | status                                       |
| Converter | SOH S T 0 0 0 0 0 1 1 CR LF | forward and reverse flow totalizers overflow |

### 1.2.2.25 SU: Noise Suppression

Parameter reflects the status of the digital filter. One data byte.

| <u>Index Number</u> | <u>Meaning</u>        |
|---------------------|-----------------------|
| 0                   | noise suppression off |
| 1                   | noise suppression on  |

Example:

|           |                     |                           |
|-----------|---------------------|---------------------------|
| Host      | SOH M 0 0 S U CR LF | filter instrument 00 on ? |
| Converter | SOH S U 1 CR LF     | yes.                      |

### 1.2.2.26 SM: Low Flow Cut-Off

Reporting of the low flow cut-off level in percent. Data format is seven bytes long.

Example:

Level of low flow cut-off of instrument 01.

|           |                             |                   |
|-----------|-----------------------------|-------------------|
| Host      | SOH M 0 1 S M CR LF         | low flow cut-off? |
| Converter | SOH S M 1 . 5 0 0 0 0 CR LF | 1.5 percent       |

**1.2.2.27 SP: Language**

Reporting of the currently set signal converter language as a three digit index number.

**TABLE 1-5. LANGUAGE INDEX**

| Index Number | Language |
|--------------|----------|
| 000          | German   |
| 001          | English  |
| 002          | French   |
| 003          | Italian  |
| 004          | Spanish  |
| 005          | Finnish  |
| 006          | Dutch    |
| 007          | Danish   |
| 008          | Swedish  |

Example:

Which language is used for the message display of Converter 23?

|           |                     |           |
|-----------|---------------------|-----------|
| Host      | SOH M 2 3 S P CR LF | language? |
| Converter | SOH S P 0 0 1 CR LF | English   |

**1.2.2.28 Z>: Totalizer Forward Flow**

Reporting of the forward flow totalizer contents. The presentation is dependent on the forward flow pulse scaling factor. Engineering units are stored in parameter EZ, paragraph 1.2.2.12. Data format is seven data bytes.(See 1.2.2.29 for example.)

**1.2.2.29 Z<: Totalizer Reverse Flow**

Reporting of the reverse flow totalizer contents. The presentation is dependent on the reverse flow pulse scaling factor. Engineering units are stored in parameter EZ, paragraph 1.2.2.12. Data format is seven data bytes.

Example:

The flow totalizer contents of signal converter 07 are to be interrogated.

|           |                             |                              |
|-----------|-----------------------------|------------------------------|
| Host      | SOH M 0 7 E Z CR LF         | totalizer engineering units? |
| Converter | SOH E Z 0 0 2 CR LF         | m <sup>3</sup> .             |
| Host      | SOH M 0 7 Z > CR LF         | forward flow total?          |
| Converter | SOH Z > 1 2 4 . 5 0 0 CR LF | 124.5 m <sup>3</sup>         |
| Host      | SOH M 0 7 Q < CR LF         | reverse flow total?          |
| Converter | SOH Z < 9 9 9 7 7 . 0 CR LF | 99977 m <sup>3</sup> .       |

### 1.2.3 Configuration Mode

Configuration mode provides the capability to change parameters or to execute a function. This is made possible by means of the function codes. The host addresses the signal converter as follows:

**NOTE**  
 Floating point numbers can be 7 characters including the decimal point. Table selection numbers can have leading zeros and be up to 3 characters.

#### Host Computer to Signal Converter

```
SOH P A1 A0 K1 K0 D7 - D0 CR LF
. . . . . . . .
. . . . . . . .
. . . . . . . Line Feed
. . . . . . . Carriage Return
. . . . . . . 8 ASCII data bytes maximum
. . . . . . . two ASCII Function Characters
. . . . . . . two digit address in ASCII format
. . . . . . . Configuration Mode
Start of Header = 01H
```

#### Response from Signal Converter:

```
Signal Converter to Host Computer
SOH K1 K0 D7 - D0 CR LF
. . . . . . . .
. . . . . . . .
. . . . . . . Line Feed = 0AH
. . . . . . . Carriage Return = 0DH
. . . . . . . maximum 8 ASCII data bytes
. . . . . . . two ASCII Function Characters
Start of Header = 01H
```

If the input is numerically out of limits, the converter responds with an error message:

```
SOH X F1 F0 CR LF
. . . . . . . .
. . . . . . . .
. . . . . . . Line Feed = 0AH
. . . . . . . Carriage Return = 0DH
. . . . . . . two digit ASCII error code
. . . . . . . X for Error Message
Start of Header
```

#### 1.2.3.1 Configuration Mode Functions



### 1.2.3.2 AD: Address

The instrument address of the signal converter can be changed via the communications link. After the change the converter responds to the new instrument address. Maximum three data bytes.

Data value range:

0 <= entry < 100

Possible error message:

| Error Code | Cause      |
|------------|------------|
| 22         | entry > 99 |

Example:

Instrument address 01 is changed to address 00.

|           |                         |
|-----------|-------------------------|
| Host      | SOH P 0 1 A D 0 0 CR LF |
| Converter | SOH A D 0 0 CR LF       |

### 1.2.3.3 AN: Display

The converter flow rate display can be in percent or engineering units. Decimal point and minus sign are ignored. Three data bytes maximum. Configuration is implemented by use of an index number:

| <u>Index Number</u> | <u>Meaning</u>            |
|---------------------|---------------------------|
| 0                   | Percent display           |
| 1                   | Engineering units display |

Example:

The signal converter whose address is 06 shall display the flow rate in percent.

|           |                           |
|-----------|---------------------------|
| Host      | SOH P 0 6 A N 0 0 0 CR LF |
| Converter | SOH A N 0 0 0 CR LF       |

### 1.2.3.4 BA: Baud Rate

The signal converter serial communications transmission speed can be reconfigured by changing the BA function parameter. After the change the converter operates with the new baud rate. No response message is issued to this configuration change. In case of an unsuccessful parameter change the converter issues an error message containing the old and still valid baud rate. The transmission baud rate is configured by an encoded index number. Refer to Table 1-6 below.

**NOTE**

The Baud rate can be set higher than the rate at which the particular combination of terminal and converter can operate. Also, any inadvertent change in the baud rate that results in a mis-match between the terminal and the converter can cause a loss of communication. A 1200 Baud rate is recommended as the upper limit for ASCII mode.

**TABLE 1-1. BAUD RATE INDEX**

| <b>Index Number</b> | <b>Baud</b> |
|---------------------|-------------|
| 000                 | 110         |
| 001                 | 300         |
| 002                 | 600         |
| 003                 | 1200        |
| 004                 | 2400        |
| 005                 | 4800        |
| 006                 | 9600        |
| 007                 | 14400       |
| 008                 | 28800       |

Note: The host will have to operate at the new baud rate when this command is given.

Possible error message:

| <u>Error Code</u> | <u>Cause</u> |
|-------------------|--------------|
| 24                | entry > 8    |

Example:

The communications transmission speed of instrument 0 is to be set to 1200 Baud.

|           |                                 |
|-----------|---------------------------------|
| Host      | SOH P 0 0 B A 3 CR LF           |
| Converter | no response (change successful) |

### **1.2.3.5 DP: Damping**

Configuration parameter for signal damping. Maximum of seven data bytes including decimal point. Engineering units are seconds.

Valid data range:

$$0 \leq \text{entry} < 100$$

Possible error messages:

| <u>Error Code</u> | <u>Cause</u>    |
|-------------------|-----------------|
| 20                | entry > = 100.0 |
| 21                | entry < 0       |

Example:

The damping of instrument 05 is to be set to 11.5 seconds.

|           |                             |
|-----------|-----------------------------|
| Host      | SOH P 0 5 D P 1 1 . 5 CR LF |
| Converter | SOH D P 1 1 . 5 CR LF       |

### 1.2.3.6 DI: Density

Configuration parameter for density in g/cm<sup>3</sup>. Maximum of seven data bytes including decimal point.

Valid data range:

$$0.01 \leq \text{entry} < 5$$

Possible error messages:

| <u>Error Code</u> | <u>Cause</u>                                                              |
|-------------------|---------------------------------------------------------------------------|
| 44                | entry > 5.0                                                               |
| 45                | entry < 0.01                                                              |
| 40                | Maximum totalizer pulse signal frequency (forward or reverse flow) 10 kHz |

Example:

The density parameter of the flow converter with instrument address 15 is to be set to 2.2845 g/cm<sup>3</sup>.

|           |                                 |
|-----------|---------------------------------|
| Host      | SOH P 1 5 D I 2 . 2 8 4 5 CR LF |
| Converter | SOH D I 2 . 2 8 4 5 CR LF       |

### 1.2.3.7 DM: Multiplexed Display

The display mode 'Multiplex Display' can be switched by an index number.

| <u>Index Number</u> | <u>Meaning</u>             |
|---------------------|----------------------------|
| 0                   | Multiplex display mode off |
| 1                   | Multiplex display mode on  |

Example:

Display mode 'Multiplex Display' is to be set for instrument 31.

|           |                       |
|-----------|-----------------------|
| Host      | SOH P 3 1 D M 1 CR LF |
| Converter | SOH D M 0 0 1 CR LF   |

### 1.2.3.8 DR: Empty Pipe Detector

The empty pipe detector function state can be switched by an index code number.

| <u>Index Number</u> | <u>Meaning</u>          |
|---------------------|-------------------------|
| 0                   | Empty pipe detector off |
| 1                   | Empty pipe detector on  |

### 1.2.3.9 DS: Empty Pipe Detector Threshold

The empty pipe detector threshold setting can be changed within the limits 0 to 155. The data presentation is always three digits in length.

Valid data range:  
 $0 \leq \text{entry} < 156$

Possible error messages:

| <u>Error Code</u> | <u>Cause</u> |
|-------------------|--------------|
| 56                | entry > 155  |

### 1.2.3.10 EI: Engineering Units for Maximum Flow

The engineering units are configured by a three digit index number for Qmax DN (QN), Qmax forward flow rate (Q>), Qmax reverse flow rate (Q<), and current flow rate (DF) in engineering units. Refer to Table 1-2 for Flow Unit Index.

Possible error messages:

| <u>Error Code</u> | <u>Cause</u>       |
|-------------------|--------------------|
| 48                | wrong index number |

Example:

Signal Converter 06 shall be set for a flow rate in l/min:

|           |                           |
|-----------|---------------------------|
| Host      | SOH P 0 6 E I 0 0 1 CR LF |
| Converter | SOH E I 1 CR LF           |

### 1.2.3.11 EZ: Engineering Units for Totalizer

The engineering units are configured by a three digit index number. This parameter defines the units for the forward flow totalizer (Z>), reverse flow totalizer (Z<), flow scaling factor (I>), and reverse flow scaling factor (I<). Refer to Table 1-3 for Totalization Unit Index.

Possible error messages:

| <u>Error Code</u> | <u>Cause</u>                      |
|-------------------|-----------------------------------|
| 52                | index number > 9                  |
| 40                | Totalizer pulse frequency > 4 kHz |

Example:

The flow converter 06 shall be set for totalizing m<sup>3</sup>.

|           |                           |
|-----------|---------------------------|
| Host      | SOH P 0 6 E Z 0 0 2 CR LF |
| Converter | SOH E Z 2 CR LF           |

### 1.2.3.12 I> and I<: Pulse Scaling Factor

I> is the configuration parameter for the forward flow scaling factor (Pulses/engineering unit). I< is the configuration parameter for the reverse flow scaling factor Engineering units are stored with the Units for Totalizer (EZ) parameter. Data presentation is seven data bytes.

Valid data range:

$0.001 \leq \text{entry} \leq 1000$

Possible error messages:

| <u>Error Code</u> | <u>Cause</u>                    |
|-------------------|---------------------------------|
| 38 (I> only)      | entry > 1000                    |
| 39 (I> only)      | entry < 0.001                   |
| 40                | maximum pulse frequency > 4 kHz |

Example:

The pulse scaling factor for Signal Converter 23 is to be set to 100.0 pulses/unit.

|           |                                   |
|-----------|-----------------------------------|
| Host      | SOH P 2 3 I > 1 0 0 . 0 0 0 CR LF |
| Converter | SOH I > 1 0 0 . 0 0 0 CR LF       |

### **1.2.3.13 IO: Current Signal Output**

The configured output signal is encoded into a three digit parameter.

| <u>Index Number</u> | <u>Meaning</u> |
|---------------------|----------------|
| 000                 | 0 - 20 mA      |
| 001                 | 4 - 20 mA      |
| 002                 | 0 - 10 mA      |
| 003                 | 2 - 10 mA      |
| 004                 | 0 - 10 - 20 mA |
| 005                 | 4 - 12 - 20 mA |

Possible error messages:

| <u>Error Code</u> | <u>Cause</u> |
|-------------------|--------------|
| 62                | entry >      |

### **1.2.3.14 IA: Alarm Current Signal Output**

In case of an alarm condition the current and frequency outputs will go to the predetermined value.

The maximum data length is three digits.

| <u>Index Number</u> | <u>Meaning</u> |
|---------------------|----------------|
| 0                   | 0%             |
| 1                   | 130%           |

**1.2.3.15 LZ: Totalizer Reset**

This instruction resets the overflow condition status message (see ST: Status Register, 1.2.2.24) and the totalizers for both flow directions. No data is transmitted.

Example:

The totalizers of instrument 00 are reset.

|           |                     |
|-----------|---------------------|
| Host      | SOH P 0 0 L Z CR LF |
| Converter | SOH L Z CR LF       |

**1.2.3.16 LV: Forward Flow Totalizer Reset**

This instruction resets the overflow condition status message (see ST: Status Register, 1.2.2.24) and the forward flow totalizer.

Example:

The forward flow totalizer of instrument 00 is to be reset.

|           |                     |
|-----------|---------------------|
| Host      | SOH P 0 0 L V CR LF |
| Converter | SOH L V CR LF       |

**1.2.3.17 LR: Reverse Flow Totalizer Reset**

This instruction resets the overflow condition status message (see ST: Status Register, 1.2.2.24) and the reverse flow totalizer.

Example:

The reverse flow totalizer of instrument 00 is to be reset.

|           |                     |
|-----------|---------------------|
| Host      | SOH P 0 0 L R CR LF |
| Converter | SOH L R CR LF       |

**1.2.3.18 NW: Meter Size**

The meter size is configured with a three digit index number. Refer to Table 1-4 for Index of Meter Sizes.

| <u>Error Code</u> | <u>Cause</u> |
|-------------------|--------------|
| 30                | entry > 45   |

**1.2.3.19 NG: System Zero Reference**

System zero reference may be configured +/- 500 Hz where the flow direction is marked by the sign designator (- for reverse, + for forward flow).

Valid data range:

- 500 <= entry <= 500

Possible error messages:

| <u>Error Code</u> | <u>Cause</u>                |
|-------------------|-----------------------------|
| 54                | entry > 500 or entry < -500 |

### 1.2.3.20 Q> and Q<: Maximum Flow Rate (Range)

Configuration of the setting of Qmax for flow rate. Engineering units are stored with parameter EI, Section 1.2.2.11 (see Table 1-2). The parameter data length is seven data bytes maximum:

Valid data range:

$$0.05 \text{ Qmax DN} \leq \text{entry} \leq \text{Qmax DN}$$

Possible error messages:

| <u>Error Code</u> | <u>Cause</u>         |
|-------------------|----------------------|
| 10                | entry > Qmax DN      |
| 11                | entry < 0.05 Qmax DN |

Example:

The maximum forward flow setting of instrument 20 is to be set to Qmax = 125 l/s.

|           |                           |
|-----------|---------------------------|
| Host      | SOH P 2 0 Q > 1 2 5 CR LF |
| Converter | SOH Q > 1 2 5 CR LF       |

### 1.2.3.21 QN: Maximum Flow Rate of Meter Size

If the Range DN parameter is set to "programmable", it is possible to directly configure the Qmax DN parameter. The configuration procedure is as described under 1.2.2.23 for Q>: Max Forward Flow Rate (refer to 3.3.3).

Valid data range:

$$0 < \text{entry} < 9\,999\,999$$

Possible error messages:

| <u>Error Code</u> | <u>Cause</u>             |
|-------------------|--------------------------|
| 12                | Qmax DN not configurable |
| 13                | entry <= 0               |

### 1.2.3.22 SM: Low Flow Cut-Off

Configuration of the low flow cut-off parameter in percent. Data length is seven digits maximum.

Valid data range:

$$0 \leq \text{entry} \leq 10$$

Possible error messages:

| <u>Error Code</u> | <u>Cause</u> |
|-------------------|--------------|
| 16                | entry > 10.0 |
| 17                | entry < 0.0  |

Example:

The low flow cut-off parameter of instrument 27 is to be set to 1.5%.

|           |                               |
|-----------|-------------------------------|
| Host      | SOH P 2 7 S M 1 . 5 0 0 CR LF |
| Converter | SOH S M 1 . 5 0 0 0 0 CR LF   |

### **1.2.3.23 SP: Language**

Configuration of the flow converter's display language as a three digit index number. Refer to Table 1-5 for Language Index.

Possible error messages:

| <u>Error Code</u> | <u>Cause</u> |
|-------------------|--------------|
| 36                | entry > 8    |

### **1.2.3.24 SU: Noise Suppression**

Switching of the noise suppression filter on or off.

| <u>Index Number</u> | <u>Meaning</u> |
|---------------------|----------------|
| 0                   | filter off     |
| 1                   | filter on      |

Example:

Noise suppression of instrument 02 has to be switched on.

|           |                       |
|-----------|-----------------------|
| Host      | SOH P 0 2 S U 1 CR LF |
| Converter | SOH S U 1 CR LF       |



## 1.3 Error Messages

---

The signal converter data received is checked for conformance with the communications protocol and for validity. If an error is detected the converter returns an error message:

```
SOH X F1 F0 CR LF
. . . . .
. . . . .
. . . . Line Feed = 0AH
. . . . Carriage Return = 0DH
. . . two digit error code in ASCII
. X for error message
Start of Header
```

### 1.3.1 Protocol and Communications Errors

| <u>Error No.</u> | <u>Cause</u>                                                                 |
|------------------|------------------------------------------------------------------------------|
| 01               | Bad operation mode (M for Monitor Mode and P for Configuration Mode only)    |
| 02               | Bad function characters                                                      |
| 03               | Configuration not permitted, since this is a protected calibration parameter |
| 04               | Number of data bytes exceeded                                                |
| 05               | Parity error                                                                 |

Example:

The instrument at address number 11 should have been configured for 100 l/min. The number of transmitted parameter configuration data bytes however, was eight instead of seven.

|           |                                     |
|-----------|-------------------------------------|
| Host      | SOH P 1 1 Q > 1 0 0 . 0 0 0 0 CR LF |
| Converter | SOH X 0 4 CR LF                     |

### 1.3.2 Configuration Error Messages

| <u>Error No.</u> | <u>Function Character</u> | <u>Cause</u>                |
|------------------|---------------------------|-----------------------------|
| 10               | Q > Q <                   | Entry > Qmax DN             |
| 11               | Q > Q <                   | Entry < 0.05 Qmax DN        |
| 12               | QN                        | Qmax DN not configurable    |
| 13               | QN                        | Qmax DN < = 0               |
| 16               | SM                        | Entry > 10                  |
| 17               | SM                        | Entry < 0                   |
| 20               | DP                        | Entry > = 100               |
| 21               | DP                        | Entry < 0                   |
| 22               | AD                        | Entry > 99                  |
| 24               | BA                        | Entry > 8                   |
| 30               | NW                        | Entry > 45                  |
| 36               | SP                        | Entry > 8                   |
| 38               | I>                        | Entry > 1000                |
| 39               | I>                        | Entry < 0.001               |
| 40               | I > I < DI EZ             | Totalizer frequency > 4 kHz |
| 44               | DI                        | Entry > 5                   |
| 45               | DI                        | Entry < = 0.01              |
| 48               | EI                        | Bad Index Number            |
| 52               | EZ                        | Entry > 9                   |
| 54               | NG                        | Entry > 500 or < -500       |
| 56               | DS                        | Entry > 155                 |
| 62               | IO                        | Entry > 5                   |

## 1.4 Remote Display

---

A "live" remote display of the 50XM1000 function can be implemented by use of a data terminal that is connected via the serial communications link. All information which is displayed by the converter's self-contained indicator can also be viewed at the data terminal in this operation mode. Also, the 50XM1000 Converter is configurable from the data terminal.

For communications 1200 or 2400 Baud is recommended. Two typical terminal types are discussed below.

- a) ANSI Terminal (i.e. VT100)
- b) Data Terminal (Teletype)

### 1.4.1 ANSI Terminal

Communication with an ANSI terminal is established with the following instruction:

```
SOH P A1 A0 ESC X A N S I CR LF
. . . . . Line Feed = 0AH
. . . . . Carriage Return = 0DH
. . . . . ANSI
. . . . . X
. . . . . ESC = 1BH
. . . . . two digit Instrument Address in ASCII
. . . . . P for Configuration Mode
Start of Header = 01H
```

The connection is terminated with the instruction.

ESC O S

The 50XM1000 Converter transmits and receives control characters for the following functions:

| <u>ESC Sequence/Control Character</u> | <u>Function</u>                             |
|---------------------------------------|---------------------------------------------|
| ESC [ 2 J ESC H                       | clear screen and cursor home                |
| ESC [ H                               | cursor home                                 |
| ESC [ 2 ; 1 H                         | position cursor at beginning of second line |
| ESC [ C                               | move cursor right                           |
| ESC [ D                               | move cursor left                            |
| BEL                                   | ring bell                                   |
| <CTRL> J                              | down                                        |
| <CTRL> K                              | up                                          |
| enter                                 | enter                                       |
| BSP                                   | clear                                       |

For proper communication, the following terminal keys must be available:

**TABLE 1-7. ANSI TERMINAL KEYS**

| Key      | ASCII Character | HEX Code |
|----------|-----------------|----------|
| 0        | 0               | 30       |
| 1        | 1               | 31       |
| 2        | 2               | 32       |
| 3        | 3               | 33       |
| 4        | 4               | 34       |
| 5        | 5               | 35       |
| 6        | 6               | 36       |
| 7        | 7               | 37       |
| 8        | 8               | 38       |
| 9        | 9               | 39       |
| .        | .               | 2E       |
| RETURN   | CR              | 0D       |
| DEL(BSP) | DEL             | 7F       |
| -        | -               | 2D       |
| LF       | <CTRL> J        | 0A       |
| VT       | <CTRL> K        | 0B       |

### 1.4.2 Data Terminal

If a data terminal is used as a remote display station, the following instruction must be used for establishing communications.

```

SOH P A1 A0 ESC X T E R M CR LF
. . . . . . . . . . . . . .
. . . . . . . . . . . . . .
. . . . . . . . . . . . . . Line Feed = 0AH
. . . . . . . . . . . . . . Carriage Return = 0DH
. . . . . . . . . . . . . . TERM
. . . . . . . . . . . . . . X
. . . . . . . . . . . . . . ESC = 1BH
. . . . . . . . . . . . . . two digit Instrument Address in ASCII
. . . . . . . . . . . . . . P for Configuration Mode
Start of Header = 01H
    
```

The connection is terminated with the instruction.

ESC O S

The 50XM1000 Converter utilizes the following control characters:

| <u>Control Character</u> |            | <u>Function</u>                           |
|--------------------------|------------|-------------------------------------------|
| <u>ASCII</u>             | <u>HEX</u> |                                           |
| CR LF                    | 0D 0A      | move cursor to beginning of next line     |
| VT CR                    | 0B 0A      | move cursor to beginning of previous line |
| CR                       | 0D         | move cursor to beginning of current line  |
| HT                       | 09         | move cursor to right                      |
| BS                       | 08         | move cursor to left                       |
| BEL                      | 07         | ring bell                                 |

For operation, refer to 1.4.1 for terminal key assignment.

PN25060



The Company's policy is one of continuous product improvement and the right is reserved to modify the information contained herein without notice.  
© 2002 ABB Inc. Printed in USA

**ABB Inc.**  
125 East County Line Road  
Warminster, PA 18974 USA  
Tel. 215-674-6000  
FAX: 215-674-7183

**ABB Instrumentation Ltd**  
Howard Road, St. Neots  
Cams. England, PE19 3EU  
Tel. +44 (0) 1480-475-321  
FAX: +44 (0) 1480-217-948

**ABB Instrumentation S.p.A**  
Via Sempione 243  
20016 Pero (Milano) Italy  
Tel: +39 (02) 33928 1  
Fax: +39 (02) 33928 240

**ABB Automation Products GmbH**  
Industriestr. 28  
D-65760 Eschborn Germany  
Tel: +49 (0) 6196 800 0  
Fax: +49 (0) 6196 800 1849